

INSTALLATION OF QUANTUM PROFILES & SKIRTING

1. Where required, use **ARDEX ARDURAPID A 45 Rapid Drying Internal Repair Mortar** to fill holes behind covers and skirting.

2. **ARDEX AF 625 Heavy Duty Contact Adhesive** provides an instant, permanent contact bond for securing profiles and skirting.

