

technical support :: recommended adhesives guide

Recommended Adhesives Guide

start > step 1 > step 2 > step 3 > finish

All Recommendations

QUANTUM FLOORING SOLUTIONS

Tel: 0161 6274222 Fax: 0161 6274333

Website: www.quantumflooring.co.uk

Email: sales@quantumflooring.co.uk

Trade Mark	Backing	Type of Bond				
		Permanent	Release	Heavy Duty / Wet Areas	Vertical	Seaming
Angles UTA (Stair Edging Trims)	Aluminium	Grip Bond PU	None	None	F60 F66	None
H-Range (Heavy Duty Nosings)	Aluminium	Grip Bond PU F61	None	None	None	None
Q-Range (Stair Nosings)	Aluminium	Grip Bond PU F61	None	None	None	None
S-Range (Slenderline Nosings)	Aluminium	Grip Bond PU F61	None	None	None	None
Z-Range (Stair Nosings)	Aluminium	Grip Bond PU F61	None	None	None	None
PVC Skirtings	PVC	None	None	None	F60 F66	None
PVC Trims	PVC	None	None	None	F60 F66	None
Transition Profiles	PVC	F60 F66	None	None	None	None
Angles UTP (Stair Edging Trims)	PVC-u	Grip Bond PU	None	None	F60 F66	None
H-Range (Heavy Duty Nosings)	PVC-u	Grip Bond PU F61	None	None	None	None
Q-Range (Slenderline Nosings)	PVC-u	Grip Bond PU F61	None	None	None	None
S-Range (Slenderline Nosings)	PVC-u	Grip Bond PU F61	None	None	None	None
Tactile	Rubber	F74* F81* F84*	None	None	None	None

F74* F81* F84* backing must be solvent wiped prior to bonding. Stair Nosings must also be mechanically fixed.