

CLEANING GUIDELINES: STAIR NOSINGS

DO NOT USE SOLVENTS!

DO NOT TRAFFIC WHILST WET!

MAKE SURE ALL CLEANING SOLUTIONS ARE REMOVED.

MATERIAL TYPE – ALUMINIUM STAIR NOSING CARRIER: S-Range, H-Range, Z-Range Q-Range

- Clean aluminium carrier with a mild detergent solution* then polish with a clean dry cloth. If required use a scouring pad to remove any ingrained dirt.
- Dry off if necessary with lint free cloth.

MATERIAL TYPE – PVC CARRIER: H-Range, Q-Range, ESN

- Clean tread with a mild detergent solution using a scouring pad to remove any heavy soiling.
- Dry off if necessary with lint free cloth.

MATERIAL TYPE – PVC TREAD: S-Range, H-Range, Z-Range Q-Range

- Both infill and nosing should be cleaned with a mild detergent solution*.
- Dry off if necessary with lint free cloth.

*Please consult recommended manufacturers guides for cleaning products.

MATERIAL TYPE – Plus-Tread TREAD

Manual

- Sweep up dust and dirt, remove large debris.
- Using a microfibre mop apply an alkaline cleaner to the floor in the correct dilution and leave for several minutes. The dilution rate depends upon how dirty the floor is and the concentrate used.
- Scrub with a deck scrubber cleaning pad attached to a multi mop handle.
- Rinse the floor with warm clean water, removing the dirty water from the floor with a microfibre mop and allow to dry. Use a double bucket to ensure that the floor is rinsed well with clean water.

Mechanical

- Vacuum up dust and dirt, remove large debris.
- Apply an alkaline cleaner in the correct dilution and leave for several minutes. (The dilution rate depends upon how dirty the floor is and the concentrate).
- Mechanically scrub using a rotary cleaning machine fitted with a cleaning pad or similar cleaning pad of the correct size.
- Wet vacuum the residue and then using a microfibre mop rinse the floor with warm clean water and vacuum dry.

MATERIAL TYPE - ECOGLO TREAD: S-Range, H-Range

1 Overview

- Regular cleaning to remove built up dirt and objects will ensure the Ecoglo products will continue performing to expectation.
- The photoluminescence will continue performing even after UV exposure or exposure to moisture.

2 Floor mounted Products

- Vacuuming or brushing with a stiff bristle head (dry or wet) is often enough to keep the strips clean. The glowing strip can also be wiped clean with a (dry or wet) sponge or cloth.
- High-pressure water (but not steam cleaning) can also be used. Observation will determine if cleaning is required however a regular clean every 4 to 6 weeks or after particularly heavy use should ensure correct performance.

NOTE: Do not use highly alkaline or acidic cleaning agents. The pH of the cleaning agents should be between pH 5 and pH 12. If cleaning agents are applied at more than pH 10, the Ecoglo material should be rinsed with pH neutral (pH 6 to pH 8) solution afterwards.

Regular cleaning:

The frequency of regular cleaning method will depend on the amount of traffic, soiling levels, desired appearance, and hygiene standards.

If you require any further details please email technical@quantum-ps.co.uk